



To use-

Remove 55 gallon drum lid.

Insert PVC former pipe into hole.

Fill 30 gallon drum with sawdust (packing tightly)

Add thin layer of sand to top of sawdust.

Carefully pull PVC former pipe up out of sawdust.

Replace 55 gallon drum lid.

Pull firebox drawer and start a small fire and insert into burner.

Stove will burn for 8 hours or longer on a charge